

Interfata diagnoza auto ODB2 mini ELM327 Bluetooth

kategoria: Kategorie > Akcesoria SAMOCHODOWE CAR Tools



Kod QR:



Support Languages: English ,Czech ,Danish,German,Spanish,French,Croatian,

hungarian,Italian,Polish,Serbian,Turkish

This hardware can match many other software still!But most of them are not free!

Works for Windows98/ME/2000/XP/Vista & 7.

This tool does not match abs and airbag system .

Elm327 bluetooth obd2 car diagnostic scanner main parameters:

elm327 chip:real PIC18F25K80 chip

elm327 obdii Output protocol mode: Bluetooth 2.0

elm327 Bluetooth Password:1234 or 0000

elm327 obdii Color: blue

elm327 interface: 16pin

elm327 software Version: V2.1

elm327 Hardware Version: V1.5

elm 327 v1.5 bluetooth Baud rate: 38400

elm327 adapter LED indicator: Yes

elm 327 v1.5 Operating voltage: 12V

elm327 v1.5 bluetooth Working current: 15A

Super MINI ELM327 Bluetooth V1.5 obd2 Functions:

Read diagnostic trouble codes, both generic and manufacturer-specific, and display their meaning (over 3000 generic code definitions in the database).

Clear trouble codes and turn off the MIL ("Check Engine" light)

Display current sensor data, including:

Engine RPM

Calculated Load Value

Coolant Temperature

Fuel System Status

Vehicle Speed

Short Term Fuel Trim

Long Term Fuel Trim

Intake Manifold Pressure

Timing Advance

Intake Air Temperature

Air Flow Rate

Absolute Throttle Position

Oxygen sensor voltages/associated short term fuel trims

Fuel System status

Fuel Pressure

Software Version:V2.1

Hardware Version:V1.5